Assembly Smart-ClimaSens



List of components









Case

Sensor (Si7021)

BLE-Module







Wires





Battery holder




Battery (CR2032)

Schematic





Prepare LED












Remove voltage regulator (optionally for current reduction)







Wire the sensor




Put the components into the case






Stick BLE-Module into the case




Stick Sensor-Module into the case



add wires to the LED (black = GND)


Connecting wires



Connect the sensor with the BLE-Module



stow the wires




Connect the LED with the BLE-Module



stow the wires

Connecting the battery



Add wires to Vcc and GND



Connect the battery holder



put in the battery



isolate the battery



Put everything into the case



close the case